



AHT Liftgates, LLC
 309 Mogie Ln.
 Acworth, Ga. 30102
 (727) 452-0174

E-Mail: parts@ahtliftgates.com
 Web: www.ahtliftgates.com

STEEL TROUBLESHOOTING GUIDE

PROBLEM	CAUSE	CORRECTION
MOTOR RUNS - PLATFORM WILL NOT RAISE	1) <i>Low hydraulic oil</i>	- Put platform on ground. Check oil level. Add new oil to within 1" from top of tank.
	2) <i>Suction Filter is plugged</i>	- Drain oil from hydraulic tank and check & clean filter
	3) <i>Flow Control valve is closed.</i>	- Flow control valve is on the block opposite the C30 cartridge valves. Loosen nut and turn valve stem counter clockwise. Retighten nut.
	4) <i>No current on lift valve in power pack</i>	- Check C30 Valve in Power pack for current. If no power replace solenoid.
	5) <i>If Current to solenoid</i>	- Switch the two valves in power pack (outside is lift valve & inside is tilt valve) Clean the valve and blow out with air. Switch valves. If it starts working then valve needs replaced.